



Easy Cast



QUALITY & ADVANCED TECHNOLOGY
PROVIDE FULL FACILITIES
AS YOU DESIRED

Easy Cast:

Induction Casting Machine is offered to dental laboratories. Function of this device is based on induction melting Technology which makes the precise and safe casting operation with all common alloys in dentistry (except titanium) possible. One of the most significant characteristics of this product is using argon gas for protection from alloys oxidation.



! Features

- Casting for all precious & non Precious Alloys (except Titanium)
- Highest Precise without any changes in work dimensions
- 100 percent security (the end of risks resulting from traditional form of casting, omission of gas capsule and air)
- Possibility of using Argon gas to maximally minimize oxidation (complete deletion of oxidation and porosity)
- Time saving (In Comparison to traditional casting method)
- Economical, Low alloy consumption
- No need to balance and adjust
- User friendly

⚙️ Technical Data

- Dimensions: 59 cm (width)×69 cm (depth)×95 cm (height)
- Maximum temperature: 1600°C
- Weight: 110 Kg
- Maximum allowable alloy weight: 60 g
- Water reservoir volume: 18 liter per minute
- Argon current rate: 15 liter per minute
- Maximum power input: 2500 w
- Power supply: 210-240 V-50 Hz

Address: Humboldt Street 12 - D40723
 Hilden - Germany
 Tel: + 49 (0) 21033373500
 Fax: + 49 (0) 21033373550
 Email: info@polarisgmbh.de
www.polarisgmbh.de

24
 Months Warranty

10
 Years Supporting of
 Spare Parts